
#### **EIS Data Analysis**

- 1. Number of Cells Used: The experiment was carried out on 12 commercially available cells.
- 2. Type of Chemistry: The cell chemistry is LiCoO2/graphite .
- 3. Testing Conditions:
  - The cells were cycled in three climate chambers set to temperatures of 25°C, 35°C, and 45°C.
  - Each cycle consisted of a 1C-rate (45mA) CCCV (constant current-constant voltage) charge up to 4.2 V and a 2C-rate (90 mA) CC (constant current) discharge down to 3 V.
  - Electrochemical Impedance Spectroscopy (EIS) was measured at nine different stages of charging/discharging during every even-numbered cycle in the frequency range.
  - All cells underwent 30 cycles at room temperature of 25°C before different temperatures were set.
  - The battery was cycled until its end of life (EoL), which is defined as when capacity drops below 80% of its initial value after undergoing these 30 cycles.
- 4. Capacity of the Cells: The cells were 45 mAh Eunicell LR2032 Li-ion coin cells.

This information provides a detailed overview of the cells used in the study and the conditions under which they were tested.

• EIS measurement of cells are taken at differrent temperature and SOC state. Information about the state measurement is given in following figure.



Note: Dataset is available at <a href="link"><u>link (https://zenodo.org/records/3633835</u>)</a>

```
In [1]:
          1 # Loading the data
              import os
              import pandas as pd
           5 # Set the path to the folder containing the data files
           6 data_folder = 'EIS Data/EIS data
              data_path = os.path.join(os.getcwd(), data_folder)
          9 # Get the file paths for all .txt files in the folder
10 file_paths = [os.path.join(data_path, f) for f in os.listdir(data_path) if f.endswith('.txt')]
          11
          12 \mid# Read the data from the files and store in a dictionary with the key as the name of the file
          13
              data dict = {}
               for file_path in file_paths:
                   file_name = os.path.basename(file_path)
          15
                   df = pd.read_csv(file_path, sep='\t')
data_dict[file_name] = df
          16
          17
          18
```

In [2]: 1 # checking weather data is fully loaded or not
2 print(data\_dict.keys())

dict\_keys(['EIS\_state\_III\_25C01.txt', 'EIS\_state\_III\_25C02.txt', 'EIS\_state\_III\_25C03.txt', 'EIS\_state\_III\_25C04.txt', 'EIS\_state\_II\_25C04.txt', 'EIS\_state\_III\_25C04.txt', 'EIS\_state\_

```
In [3]: 1 EIS_state_III_25C01 = data_dict['EIS_state_III_25C01.txt']
             # converting the data into dataframe
          3 EIS_state_III_25C01 = pd.DataFrame(EIS_state_III_25C01)
          4 # shape of the data
          5 print(EIS_state_III_25C01.shape)
6 # Print the first 5 rows of the data
          7 EIS_state_III_25C01.head()
         (15660, 7)
Out[3]:
               time/s cycle number
                                   freq/Hz Re(Z)/Ohm -Im(Z)/Ohm |Z|/Ohm Phase(Z)/deg
         0 9651.00252
                              1.0 20004.4530
                                                         -0.03055 0.39301
                                               0.39182
                                                                             4.45806
                             1.0 15829.1260
         1 9651.14552
                                              0.39693
                                                        -0.01230 0.39712
                                                                            1.77458
         2 9651.28752
                            1.0 12516.7030 0.40190
                                                        0.00234 0.40191
                                                                            -0.33358
                            1.0 9909.4424 0.40953
         3 9651.42952
                                                        0.01629 0.40986
                                                                            -2.27833
         4 9651.59352
                            1.0 7835.4800 0.41789 0.02743 0.41879
                                                                            -3.75550
In [4]: 1 # check the column names
          2 EIS_state_III_25C01.columns
          3 # Remove the spaces in the column names before and after the column names
          4 EIS_state_III_25C01.columns = EIS_state_III_25C01.columns.str.strip()
          5 # check the column names
          6 EIS_state_III_25C01.columns
dtype='object')
         Analysis
          • From the graph it can be seen that the as the cell ages how resistance changes from cycle 1 to cycle 261.
         EIS State_I_25C
In [5]: 1 EIS_state_I_25C01 = data_dict['EIS_state_I_25C01.txt']
             # converting the data into dataframe
          3 EIS_state_I_25C01 = pd.DataFrame(EIS_state_I_25C01)
          4 # shape of the data
          5 print(EIS_state_I_25C01.shape)
6 # Print the first 5 rows of the data
7 EIS_state_I_25C01.head()
         (21000, 7)
Out[51:
               time/s cycle number freq/Hz Re(Z)/Ohm -lm(Z)/Ohm |Z|/Ohm Phase(Z)/deg
         0 7520.78391
                             1.0 20004.4530
                                             0.40128
                                                        -0.02956 0.40237
                                                                             4.21264
         1 7520.92691
                             1.0 15829.1260 0.40688 -0.01046 0.40701
                                                                             1.47198
                            1.0 12516.7030 0.41389
         2 7521.06891
                                                        0.00415 0.41391
                                                                            -0.57420
         3 7521.21091
                              1.0 9909.4424 0.42152
                                                        0.01708 0.42187
                                                                             -2.31990
         4 7521.37491
                              1.0 7835.4800 0.42905
                                                        0.02692 0.42990
                                                                             -3.59049
In [6]: 1 # check the column names
          2 EIS_state_I_25C01.columns
          3 # Remove the spaces in the column names before and after the column names
4 EIS_state_I_25C01.columns = EIS_state_I_25C01.columns.str.strip()
          5 # check the column names
          6 EIS_state_I_25C01.columns
```


dtype='object')

In [ ]: 1 %pip install plotly

```
In [9]: 1 import plotly.express as px
            # Select only the desired cycle numbers
            cycle_numbers = [1, 100, 200, EIS_state_I_25C01['cycle number'].max()]
          4
            # Filter the data to include only the selected cycle numbers
         7
            EIS_filtered = EIS_state_I_25C01[EIS_state_I_25C01['cycle number'].isin(cycle_numbers)]
         8
            fig = px.line(EIS_filtered, x="Re(Z)/Ohm", y="-Im(Z)/Ohm", color='cycle number')
         11
            # Update the Layout of the figure
            fig.update_layout(

title="EIS Data of Cell 01 State-I at 25 degC",
         12
         13
                xaxis_title="Re(Z)/Ohm",
yaxis_title="-Im(Z)/Ohm",
         14
         15
         16
                 font=dict(
         17
                     family="Times New Roman",
         18
                    size=18,
color="black"
         19
         20
         21
                legend=dict(
         22
23
                     title="Cycle Number",
                     font=dict(
         24
                         family="Times New Roman",
         25
26
                         size=14,
                         color="black"
         27
         28
                )
         29
30
            )
         31
            # Update the style of the lines
         32
            fig.update_traces(
         33
34
                line=dict(
                    width=4
         35
                     dash="solid"
         36
         37 )
         38
         39
            # add axis line and ticks
         40 fig.update_xaxes(showline=True, linewidth=2, linecolor='black', mirror=True, ticks="outside")
41 fig.update_yaxes(showline=True, linewidth=2, linecolor='black', mirror=True, ticks="outside")
42 # make background white
            fig.update_layout(plot_bgcolor='white')
        49
            # Make y-axis to start it from 0
            fig.update_yaxes(range=[0, 0.7])
         51
            # add grid
            52
         53
```

### EIS Data of Cell 01 State-I at 25 degC



#### **Analysis**

55

56


fig.show()

- From the graph it can be seen that the as the cell ages how resistance changes from cycle 1 to cycle 350.
- The point where each curve intersect with the x-axis at far left side indicate the ohmic resistance. As you can see that the overall the resistance is increasing as the battery cell ages.
- Diameter of semi-circle represents the charge transfer resistance. As the cycle number increases, it appears that the charge transfer resistance increases, indicating a degradation in cell performance.
- The straight line in the low frequency region represents the warburg impedance associated with the diffusion process.

```
In [12]: 1 import plotly.graph_objects as go
                   # Function to add traces based on filtered data
def add_traces_to_fig(fig, data, temperature, mode='lines', dash='solid', marker_symbol=None):
                                colors = ['royalblue', 'green', 'firebrick', 'purple'] # For different cycle numbers
for idx, cycle_num in enumerate(cycle_numbers):
                                       filtered_data = data[data['cycle number'] == cycle_num]
                                       fig.add\_trace(go.Scatter(x=filtered\_data['Re(Z)/Ohm'], y=filtered\_data['-Im(Z)/Ohm'], y=fil
                   8
                                                                                     mode=mode,
                                                                                     name=f'{temperature} - Cycle {cycle_num}',
                  10
                  11
                                                                                     line=dict(
                                                                                            color=colors[idx].
                  12
                  13
                                                                                            width=4,
                  14
                                                                                            dash=dash),
                  15
                                                                                     marker=dict(
                  16
                                                                                            symbol=marker_symbol
                  17
                  18
                  19 EIS state I 35C01 = data dict['EIS state I 35C01.txt']
                        # converting the data into dataframe
                  20
                  21 EIS_state_I_35C01 = pd.DataFrame(EIS_state_I_35C01)
                  # converting the data into dataframe
                  26 EIS_state_I_45C01 = pd.DataFrame(EIS_state_I_45C01)
                  29
                  30 # Select and filter data for 25C
31 cycle_numbers = [1, 100, 200, 300]
                        EIS_filtered25 = EIS_state_I_25C01[EIS_state_I_25C01['cycle number'].isin(cycle_numbers)]
                  33
                  34 # Select and filter data for 35C
                  35 EIS_filtered35 = EIS_state_I_35C01[EIS_state_I_35C01['cycle number'].isin(cycle_numbers)]
                  36
                  37 # Select and filter data for 45C
38 EIS_filtered45 = EIS_state_I_45C01[EIS_state_I_45C01['cycle_number'].isin(cycle_numbers)]
                  40 # Create a figure
                  41 fig = go.Figure()
                  42
                  43 # Add traces for each temperature
                  44 add_traces_to_fig(fig, EIS_filtered25, "25 degC", mode='lines+markers', marker_symbol='square')
45 add_traces_to_fig(fig, EIS_filtered35, "35 degC", mode='markers', marker_symbol='diamond')
46 add_traces_to_fig(fig, EIS_filtered45, "45 degC", mode='markers', marker_symbol='star')
                  47
                  48 # Rest of your figure updates
                  49 # add axis line and ticks
                  fig.update_xaxes(showline=True, linewidth=2, linecolor='black', mirror=True, ticks="outside") # , range=[0, 0.7]
fig.update_yaxes(showline=True, linewidth=2, linecolor='black', mirror=True, ticks="outside")
                  52
                        # make background white
                  53 fig.update_layout(plot_bgcolor='white')
                        # Move x-label and y-label to the center
                  fig.update_layout(xaxis=dict(title=dict(standoff=10)), yaxis=dict(title=dict(standoff=10)))

# Icncrease x-axis and y-axis tick font size and font family
                        fig.update_xaxes(tickfont=dict(size=18, family='Times New Roman', color='black'))
                  58 fig.update_yaxes(tickfont=dict(size=18, family='Times New Roman', color='black'))
                  59 # add arid
                  60 fig.update layout(xaxis=dict(showgrid=True, gridwidth=1, gridcolor='LightPink'),
                                                         yaxis=dict(showgrid=True, gridwidth=1, gridcolor='LightPink'))
                  62 # fig size
                  63 | #fig.update_layout(height=800, width=1000)
                  64 # make y-axis range to start from 0
                  65 fig.update_yaxes(range=[-.1, 0.6])
                  66 fig.update_xaxes(range=[0.25, 2.5])
                  # Update the Layout of the figure
                  73 fig.update_layout(
                  74
                                title="EIS Data of Cell 01 State I at Different Temperatures".
                                xaxis_title="Re(Z)/Ohm"
                  75
                                yaxis_title="-Im(Z)/Ohm",
                  76
                  77
                                font=dict(
                  78
                                       family="Times New Roman",
                  79
                                        size=18,
                  80
                                        color="black"
                  81
                               ))
                  82
                       fig.show()
                  83
                  84
```

### EIS Data of Cell 01 State I at Different Temperatures



#### Observations


- At 25°C, the impedance values appear to increase progressively with the cycle number, particularly evident in the high-frequency region. This increase suggests that the cell's internal resistance is growing with continued cycling, indicating degradation processes occurring within the cell.
- At 35°C, a similar pattern emerges. However, the semicircles appear slightly more pronounced and compact. The overall resistance seems to be slightly lower than that of 25°C initially (Cycle 1), but it does show increasing tendencies with cycling, suggesting that the temperature increment speeds up certain reactions and degradation.
- At 45°C, the impedance values seem to start off higher even at Cycle 1 when compared to the other two temperatures. The trend of increasing impedance with cycle number persists. This might imply that at this elevated temperature, the degradation processes are more pronounced right from the beginning for this type of perticular cell.

#### Detailed Data Visualization of cells at different temperatures and different stages


```
In [13]:
               import pandas as pd
            2 import plotly.express as px
            4 def plot_EIS_data(state, temp, cell_num, data_dict):
            5
                     # Construct the filename
                    filename = f"EIS_state_{state}_{temp}C{cell_num:02d}.txt"
            6
            8
                    # Fetch the data from the dictionary
            9
                    data = data_dict[filename]
           10
                    # Convert the data to a DataFrame
           11
           12
                    df = pd.DataFrame(data)
           13
           14
                    # Rename the columns
           15
                    16
                    # Filter the data by cycle number
cycle_numbers = [1, 100, 200, df['cycle number'].max()]
           17
           19
                    df_filtered = df[df['cycle number'].isin(cycle_numbers)]
           20
           21
           22
                    fig = px.line(df_filtered, x="Re(Z)/Ohm", y="-Im(Z)/Ohm", color='cycle number')
           23
24
                    # Update layout and styling...
           25
                         # Update the layout of the figure
                    fig.update_layout(
    title="EIS Data of Cell 01 State V at 45 degC",
    xaxis_title="Re(Z)/Ohm",
           26
           27
           28
           29
                         yaxis_title="-Im(Z)/Ohm",
           30
                         font=dict(
                              family="Times New Roman",
           31
           32
                              size=18,
           33
                              color="black"
           34
35
                         legend=dict(
           36
                              title="Cycle Number",
           37
                              font=dict(
                                  family="Times New Roman",
           38
39
                                  size=14,
           40
                                  color="black"
           41
                             )
           42
                        )
           43
                    )
           44
           45
                    # Update the style of the lines
           46
                    fig.update_traces(
                         line=dict(
           48
                              width=4
           49
                              dash="solid"
           50
                        )
           51
           52
           53
54
                    # add axis line and ticks
                    fig.update_xaxes(showline=True, linewidth=2, linecolor='black', mirror=True, ticks="outside") fig.update_yaxes(showline=True, linewidth=2, linecolor='black', mirror=True, ticks="outside")
           55
           56
57
                    # make background white
fig.update_layout(plot_bgcolor='white')
                     # Move x-label and y-label to the center
           58
           59
                    fig.update_layout(xaxis=dict(title=dict(standoff=5)), yaxis=dict(title=dict(standoff=5)))
                    # Icncrease x-axis and y-axis tick font size and font family
fig.update_xaxes(tickfont=dict(size=24, family='Times New Roman', color='black'))
fig.update_yaxes(tickfont=dict(size=24, family='Times New Roman', color='black'))
           60
           61
           63
                    # Make y-axis to start it from 0
           64
                    #fig.update_yaxes(range=[0, 0.7])
           65
                     # add grid
                    fig.update_layout(xaxis=dict(showgrid=True, gridwidth=0.5, gridcolor='LightPink'),
           67
                                         yaxis=dict(showgrid=True, gridwidth=1, gridcolor='LightPink'))
           68
           69
                    # Update the title based on the parameters
fig.update_layout(title=f"EIS Data of Cell {cell_num:02d} State {state} at {temp} degC")
           70
71
           72
            73
                     fig.show()
           74
```

#### Plotting the Data of cell 01 at 25 degC


# EIS Data of Cell 01 State I at 25 degC




# EIS Data of Cell 01 State II at 25 degC




EIS Data of Cell 01 State III at 25 degC




EIS Data of Cell 01 State IV at 25 degC



EIS Data of Cell 01 State V at 25 degC




# EIS Data of Cell 01 State VI at 25 degC




No data available for state VII No data available for state VIII

EIS Data of Cell 01 State IX at 25 degC




#### Plotting the Data of cell 01 at 35 degC


# EIS Data of Cell 01 State I at 35 degC




# EIS Data of Cell 01 State II at 35 degC




### EIS Data of Cell 01 State III at 35 degC




EIS Data of Cell 01 State IV at 35 degC



EIS Data of Cell 01 State V at 35 degC




EIS Data of Cell 01 State IX at 35 degC




### Plotting the Data of cell 01 at 45 degC


# EIS Data of Cell 02 State I at 45 degC




# EIS Data of Cell 02 State II at 45 degC




### EIS Data of Cell 02 State III at 45 degC



EIS Data of Cell 02 State IV at 45 degC



EIS Data of Cell 02 State V at 45 degC



EIS Data of Cell 02 State IX at 45 degC

